TOP AND CABINET PARTS

For Models: WTW6600SW0, WTW6600SG0, WTW6600SB0
(White) (Biscuit) (Black)

AUTOMATIC WASHER



TOP AND CABINET PARTS

For Models: WTW6600SW0, WTW6600SG0, WTW6600SB0
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	8566931	Use & Care Guide
	8567470	Installation Instructions (DVD)
	8567037	Tech Sheet
	8566929	Quick Start Guide
	8577781	Wiring Diagram
	8567168	Energy Guide
2		Top
	8565311	White
	8565312	Biscuit
	W10053420	Black
3	8576639	Frame Assembly, Cabinet Top (Includes Item 31)
4	8576784	Sound Absorber, Cabinet
5		Cabinet
	8566156	White
	8566157	Biscuit
	W10050330	Black
6	8566090	Panel, Rear
7	8543781	Retainer, Drain Hose Storage
8	8578225	Sound Absorber, Cabinet
9	8576475	Ball, Suspension (4)
10	8564009	Damper Assembly, Tub Suspension (Set Of 4)
11	1157158	Screw, 8−18 x 3/8
12	8563602	Locator, Top (2)
13	W10078270	Screw, Lid Hinge Mounting (4)
14		Hinge Wire (2)
	8563965	(L.H.)
	8572974	(R.H.)
15		Hinge, Spring Assembly (Glass Lid)
	8563962	(Left)
	8563963	(Right)
16	8563785	Lock, Top− Front (2)
17	W10052730	Bearing, Lid Hinge (2)
19		Lid, Glass Assembly
	8565267	Brilliant White Aluminum
	8576485	Gold Dust
	W10071520	Black
20	8578826	Foot Assembly, Leveling (4)
21		Dispenser, Fabric Softener
	W10059150	White
	W10052670	Biscuit
	W10052680	Elephant
22		Bezel, Fabric Softener Dispenser
	8566210	White
	8580016	Biscuit
	8580017	Elephant
23		Dispenser, Bleach
	W10059160	White
	W10052690	Biscuit
	W10052700	Elephant
24		Bezel, Bleach Dispenser
	8566211	White
	8580018	Biscuit
	8580019	Elephant
25		Dispenser, Detergent
	8564976	White
	W10059170	Biscuit
	W10059180	Elephant
26		Bezel, Detergent
	8564979	White
	W10045190	Biscuit
	W10045210	Elephant Dispenser
27	8543779	Nozzle Assembly, Fresh Water
28	371503	Clamp, Hose
29	W10059230	Lock Assembly, Lid
30		Bezel, Lid Lock
	8572019	White
	8563939	Biscuit
	W10052520	Black
31	8564458	Absorber, Impact
32	8564456	Hinge, Top (2)
33	18849	Pad, Top Hinge (2)
34	343641	Screw, 10−16 x 1/2 (2)
35	8563941	Cover, Harness
36	693995	Screw, 8−18 x 3/8
37	8543784	Bracket, Drain Hose
39	8281136	Screw, 10−16 x 3/4
40	8576476	Spacer, Rear (Cabinet/Top)
41	370451	Clamp, Hose
42	371503	Clamp, Hose
43	3400061	Screw, 10−16 x 9/16
44	90016	Clip, Harness (4)
45	8281736	Wire, Ground Jumper
46	3400076	Screw, 10−32 x 5/8
47	3390647	Screw, 8−18 x 1/2
48	8577896	Washer, Suspension Umbrella

CONTROL PANEL PARTS

For Models: WTW6600SW0, WTW6600SG0, WTW6600SB0
(White) (Biscuit) (Black)



CONTROL PANEL PARTS

For Models: WTW6600SW0, WTW6600SG0, WTW6600SB0
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1	W10104830	Control Unit Assembly, Machine & Motor
2	8565260	Gasket, Valve Tray
3		Tray Assembly, Console (Includes Items 2 & 4)
	8565304	White
	8565306	Biscuit
	8565305	Black
4	8565259	Gasket, Console/Tray
5	W10059320	Valve, Log Assembly
6		Knob, Control
	8574885	White
	8580119	Biscuit
	8580118	Black
7	8564290	User Interface
8	W10004990	Screw, 6−20 x 1.2
9		Console
	W10070060	White
	W10070070	Biscuit
	W10070080	Black
10	8564265	Cover, Rear− User Interface
11	W10003770	Screw, 6−19 x 1/2 (3)
12	W10022060	Nut, Push−In (3)
13	W10045100	Harness, Upper
14	8565324	Screw, 10−16 x 1.75
15	8281136	Screw, 8−18 x 3/4
16	3407203	Cord Assembly, Power
17	98460	Nut, Push−In (2)
18	3976300	Washer, Water Inlet Hose (1−1/16 x 5/8)(4)
19		Hose, Water Inlet
	8571377	Blue Coupler
	8571378	Red Coupler
20	488649	Screw, Power Cord Ground
21	3407187	Harness, Thermistor

MOTOR, BASKET AND TUB PARTS

For Models: WTW6600SW0, WTW6600SG0, WTW6600SB0
(White) (Biscuit) (Black)



MOTOR, BASKET AND TUB PARTS

For Models: WTW6600SW0, WTW6600SG0, WTW6600SB0
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1	8578929	Cap, Impeller
2	W10076270	Screw & Washer Assembly
3	W10076260	Washer
4	8542666	Tub Ring
5	8572540	Hose Pressure Switch
6	W10076230	Impeller (Washplate)
7	8533953	Screw, 8−16 x 1.000 (6)
8	8545948	Hub, Basket−Driven (Includes Item 9)
9	8545953	Hub, Basket−Driver (Includes Item 8)
10	8557267	Basket Assembly (Includes Items 7, 8, & 9)
11	8572660	Tub & Drive Shaft Assembly
12	8546680	Wrap, Tub
13	8542674	Weight, Tub Counterbalance
14	W10004910	Screw, 12−16 x 1−1/4 (2)
15	8557839	Shield, Drive Motor (Includes Item 16)
16	8565172	Tube, Buffer (Set Of 4)
17	8565170	Stator, Motor (Includes Item 18)
18	8557836	Plate, Stator (Set Of 2)
19	W10076010	Screw, 1/4−20 x .968 (4)
20	8565188	RPS Assembly
21	8565177	Rotor, Main Drive Motor (Includes Item 22)
22		Bolt, Rotor Assembly Non−Serviceable (Supplied W/Rotor)
23	W10058730	Harness, Lower (Includes Item 5)
24	8566197	Filter, Dual Pump Hood
25	8533928	Screw, 8−18 x 3/4 (2)
26	8533987	Retainer, Push−In
27	W10005430	Clamp, Pressure Hose Retainer
28	8533957	Screw, 10−16 x 1/2
29	8564017	Cup, Suspension (4)

PUMP PARTS

For Models: WTW6600SW0, WTW6600SG0, WTW6600SB0
(White) (Biscuit) (Black)



Illus. No.	Part No.	DESCRIPTION
1	W10049390	Pump Assembly, Drain
2	8571715	Hose, Drain
3	8543774	Hose, Recirc
4	8578573	Pump Assembly, Recirc
5	8534063	Screw, 10−14 x 1.000
6	370449	Clamp, Hose
7	8269146	Clamp, Hose
8	8317496	Clamp, Hose
9	8182771	Grommet, Pump Mounting (4)
10	8534021	Clamp, Recirc Hose Retainer
11	8533943	Screw, 10−16 x 3/4
12	8578572	Shield, Recirc Pump
13	8576642	Retainer, Drain Hose
14	3347868	Cable Tie
15	8182769	Hose, Recirc Pump
16	8182770	Clamp, Recirc Pump Hose
17	8182767	Hose, Drain Pump
18	8182768	Clamp, Drain Pump Hose

OPTIONAL PARTS (NOT INCLUDED)

For Models: WTW6600SW0, WTW6600SG0, WTW6600SB0
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
		PAINT, TOUCH−UP (1/2oz.)
	72017	White
	4392899	Biscuit
	72032	Black
		PAINT, PRESSURIZED SPRAY (12 oz.)
	350938	Primer, Gray
	350930	White
	4392901	Biscuit
	786020	Black
		PAINT, BULK (1 qt.)
	799344	White (Uncut)
	4392900	Biscuit (Uncut)
	786032	Black (Uncut)
		WATER SYSTEM PARTS
	285442	Connector Kit, Plastic Drain Hose
	285321	Sleeve Kit, (Contains 2 Sleeves)
	285320	Siphon Break Kit
	367031	Drain Protector
		SEALER
	285195	Sealer, Gasket (.20 Fl. Oz.) (6 ml)
		COUPLING
	384496	Coupling, Hose